*FIG. 1*


34
REMOTE OFFICE PLATFORM
46
DATABASE
16
42
44
72
12
14
56
SERVICE CONTROLLER
52
PBX
CTI
SWITCH CONTROLLER
MN
SECURITY SYSTEM
MOBILITY APPLET
56p
MN
50
14p
PBX
40
SWITCH
DATA
20
PSTN
18
30
28
MN
32
22
24
76
38
74
26
36

*FIG. 2*


60
TEXT LABELED INTERFACE FOR REMOTE
64
VOICE MAIL
EMAIL
FAX
TEXT DISPLAY SCREEN
66
75
76
LINE 1
CON
62
78
LINE 2
CON
MOBILE
XXX-XXX-XXXX
70
TFR
CONF
HOLD
MUTE
FWD

*FIG. 3*


100
END REMOTE SESSION
110
130
MOBILITY NUMBER ?
NO
EXIT REMOTE PLATFORM
120
YES
ACTIVATE MOBILITY PROCESS
140
CAN MOBILE ACCEPT MOBILITY GUI ?
150
NO
YES
PUSH GUI TO MOBILE DEVICE
155
MAINTAIN SESSION ACTIVE IN NETWORK ROUTE CALLS TO MOBILITY NUMBER
160
REMOTE WORKER LOG IN ?
NO
170
YES
DEACTIVATE MOBILITY PROCESS
180
RUN REMOTE WORKER SESSION
190

*FIG. 4*


76
PHONE \ ADDBK \ SETTING \ STATUS
78
CURRENT NUMBER
732-555-1234
80
81
NEW MESSAGES
VOICE MAIL
82
PHONE NUMBER
84
LINE 1
HOLD
90
RELEASE
86
LINE 2
Xfer
CONFERENCE
88

*FIG. 5*


230
200
20
IP NETWORK
REMOTE OFFICE PLATFORM
USER
SERVICE CONTROLLER
72
MOBILITY PROCESS
16
12
14
PBX
220
VRU
DATABASE
46
SWITCH CONTROLLER
210
RECEIVED FROM MOBILE DEVICE
COMMAND
VOICE
DTMF
"HOLD"
# 1
HOLD CALL
"TRANSFER TO EXTENSION 1234"
#21234
TRANSFER CALL